


RS422 cable for connecting an FP8 to a PC (Requires 100ohm resistor modification inside FP8)

Female USB receptacle for connection to FP8

- 1 red
- 2 white
- 3 green
- 4 black (thin)
- 5 shield black (thick)



Note there is no ground wire on the FP8 (Nomad's) serial port so ground must be connected elsewhere. If the FP8 (Nomad) and PC are powered by the same power supply that should be sufficient.

Title		
FP8 TO PC CABLE wiring diagram		
Size	Document Number	Rev
A	Zaxcom	1
Date:	Tuesday, February 23, 2016	Sheet 1 of 1