

## Nomad Lite Record Routing

The record routing in Nomad Lite is slightly different than the card routing in Nomad 10 or 12. Nomad Lite doesn't have a record enable matrix or a card routing matrix. With Nomad Lite you can route all your inputs and all your record busses to any one of the 10 record tracks with the "Record Routing" menu located in the Main Menu

MAIN MENU		RECORD ROUTING	
META DATA	>	CARD1	(OFF)
PLAYBACK CONTROL	>	CARD2	(OFF)
RECORD ROUTING	>	CARD3	(OFF)
MIRROR ENABLES	>	CARD4	(OFF)
MY NOMAD (CARD/MIRROR)	>	CARD5	(OFF)
FADER ASSIGN	>	CARD6	(OFF)
MEMORY STORE/RECALL	>	CARD7	(OFF)
ABOUT NOMAD	>	CARD8	(OFF)
MODE	>	CARD9	(OFF)

In the record routing page you select and highlight which card track you want to record on then you can choose what source you want to assign and record on that channel. You can choose between all 10 analog inputs or any of your 6 output busses.

RECORD ROUTING	
CARD1	Input 1
CARD2	Input 2
CARD3	Out 1
CARD4	Out 2
CARD5	(OFF)
CARD6	(OFF)
CARD7	(OFF)
CARD8	(OFF)
CARD9	(OFF)